

INSTRUKCJA MONTAŻU / ASSEMBLY INSTRUCTION



Ax5	Bx1	Cx1	
Dx1	Ex1	Fx1	
Gx2	Hx1	Ix1	
Jx2	Kx6	Lx1	Mx2
1/4"x2-1/4"	1/4"x1-3/4"	5/16"x1-1/8"	5/16"x7/8"
Nx6	Ox1	Px2	
		1/4"x1-7/8"	

